



Shaker, Bird & Teddy Set

Three toys with one lesson in common: do something, and something happens. Turn the shaker and the beads pour; move the eyes and the bird pulls a face; knock the teddy and it wobbles back with a squeak.

AGE
6 months +

CONTENTS
3 toys

MARKET
Dual — Home & Education

ARTICLE NUMBERS
76026 · 76035 · 76025

WHAT IS IN THE SET



76026
Magic Shaker
13.5 × 5.5 × 12 cm



76035
Crazy Eyed Bird
9.5 × 9.5 × 15 cm



76025
Roly Poly Teddy Bear
9.5 × 8.5 × 12 cm

WHAT CHILDREN LEARN



Cause & effect
Turn, push, knock — three different actions, three reliable results. Prediction begins here.



Fine motor
Two-handed turning of the shaker; finger-tip work on the bird's eyes, a whole-hand push on the teddy.



Visual tracking
Beads flowing chamber to chamber; a bear rocking back to centre — slow movement the eye can follow.



Language
Up and down, in and out, again and stop. The bird's faces invite happy, sad, surprised.



Emotional literacy
The bird's movable eyes make faces a child can copy, name and laugh at.



Social skills
Push the teddy to a friend and it comes back. A wobble is a turn a baby can take.

ONE SET, FIVE YEARS OF PLAY



TRY THIS ON DAY ONE



Watch It Pour

6–12 months · Turn the shaker slowly so the beads flow; let the child's eyes follow them down.



Wobble Back

6–15 months · Push the teddy over, let it rock back. Wait for the child to push it too.



Make a Face

12 months – 3 years · Move the bird's eyes into a new position and copy the face together.

TOPIC LINKS

Cause and effect

Faces and feelings

Up and down

In and out

Sounds

Taking turns

Provisional — Set composition follows the TOLO sets list of September 2026. Article numbers and dimensions from the 2026 specification sheet. Activity content to be reviewed by a qualified early-years advisor before publication.

